



# Check Your Chamber for Water Contamination!

Water Ingress will cause the caliper to fail and invalidate warranty.

Contaminated Air Chambers cause water ingress.

The chamber should be replaced if there are signs of contamination.

## Push Rod Corrosion



## Lever Corrosion



CHECK  
YOUR

**AIR CHAMBER  
FOR WATER INGRESS**

